

-PREP STEPS-



**Overlay on Surface Previously Covered
with Carpet, Linoleum or Vinyl Tile**



The general issue with these surfaces is residual mastic or glue.

Our prep steps are as follows...

- 1) Clean all loose materials off floor**
- 2) Mop with soap and water**
- 3) Allow to dry completely**
- 4) Patch any tack strip holes with Serico**
- 5) Trowel on skim coat of Serico all over to create
smooth surface-could take more than one coat**
- 6) Allow to sit at least Overnight for full cure**
- 7) Sand Serico lightly & clean**
- 8) Overlay project**
- 9) Allow to sit overnight to dry**
- 10) Next day-sand rough areas with 220 grit on a palm sander**
- 11) Clean with water, hydrate and stain**
- 12) Allow stain to sit for 3 hours**
- 13) Clean residue and apply Hardener
3 coats with at least 30 minutes between**
- 14) Buff in Brown Gravy Wax
Buff to a sheen approx 10 min later OR**
- 15) If High-Gloss is desired, skip Liquid Hardener and Wax---
instead, roll-on Solvent Topcoat in two coats 2 hours apart.**