

## **-PREP STEPS-**



### **Overlay on Formica or Corian**



**Formica is a very common, very difficult to adhere surface. However, there are primers out there designed to adhere to Formica without wasting time trying to sand the surface. When using a product like “Serico”, surface can be leveled at same time to eliminate drip edges and seams.**

**Our prep steps are as follows...**

- 1) Clean with Denatured Alcohol**
- 2) Tape any seams with fiberglass tape and bed layer of Serico**
- 3) Trowel on skim coat of Serico over everything**
- 4) Allow to sit Overnight for full cure**
- 5) Sand Serico lightly & clean**
- 6) Overlay Counter**
- 7) Allow to sit overnight**
- 8) Next day-sand rough areas with 220 grit on a palm sander**
- 9) Clean with water, hydrate and stain**
- 10) Allow stain to sit for 3 hours**
- 11) Clean residue and apply Hardener *if non-food surface***
- 12) Wax with Brown Gravy Wax**
- 13) If food is to be prepared or handled on surface, or a HIGH\_Gloss sheen is preferred, skip Hardener and wax---instead apply Solvent Topcoat**